

Baby Booster Seat Chair




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Parts list

Please confirm if you have all the parts before realize assembly.

A. Left leg	1	G. Eating tray	1
B. Right leg	1	H. Beam	1
C. Table leg	2	I. Footrest	1
D. Table	1	J. Back	1
E. Nuts	14		
F. T-shaped metal sheet	1		



Assembly and use

Read these instructions carefully before use, and keep the instructions well for future reference. If you do not follow these instructions, your child's safety cannot be guaranteed.

1. Attach the beam to a table leg (fig. 1)
2. Attach the table next to the leg (fig. 2)
3. Add the leg to the side of the table (fig. 3)
4. Tighten the nuts (fig. 4)
5. Final assembly of the table (fig. 5)
6. Attach the back to the left leg as shown (fig. 6)
7. Attach the footrest to the left leg with direction as shown (fig. 7)
8. Attach the right leg to the seat (fig. 8)
9. Tighten the nuts (fig. 9)
10. Final assembly of the chair (fig. 10)
11. Now it can be used as a table and chair (fig. 11)

WARNING

Cleaning

1. The plastic parts can be cleaned with sponge and warm soapy water.
2. For the tapestry, you can use a cloth with warm water and neutral soap.
Don't use abrasive cleaners, don't put it in the washing machine and don't wet it in water.
3. The parts of cloth can be cleaned by a sponge and warm water.
4. Please store the chair in a dry and clean place.

Caution

1. Make sure all parts are locked in place before using.
2. Always use the belt provided when your child is in the chair.
3. Never leave your child alone without supervision. This chair is intended only for children less than 15 Kg.
4. Don't use the eating chair unless all components are properly secured and adjusted.
5. This eating chair is designed to be used by only one child each time.
6. Keep the eating chair away from dangerous things, such as heaters, fires, campfires, etc.
7. Never load the chair when your child is in it.
8. Once the chair is assembled, make sure all threads / nuts are fixed safely and check them periodically.
9. Make sure the safety straps are correctly fitted.
10. Don't use the chair if there is any part broken or missing.
11. This eating chair is designed for children from 6 to 36 months.
12. The assembly of the chair must be realized by an adult.

WARNING!

- Falling hazard: Prevent your child from climbing on the product.
- Not to use the product until the child can sit up unaided.
- Be aware of the risk of tilting when your child can push its feet against a table or any other structure.

Comply to EN 14988:2017+A1:2020

If you have any questions, please contact our customer care center.
Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK LTD
Unit 27, Perivale Park,
Horsenden lane South
Perivale, UB6 7RH
MADE IN CHINA





Chair assembly



12. Attach the chair to the beam (fig. 12).
13. Place the food tray on top of the armrest, adjust it in the groove.
- 14 Final assembly of the eating chair (fig. 14).
15. Press the seat release button as shown in the picture, while pressing the chair which will raise (fig. 15).
16. The food tray has 3 different positions. If you want to change the position, press the handle (A) on both sides of the tray (fig. 17).
17. Press the button as shown in the picture to change the position of the back (fig. 18).



Chair assembly



Chair assembly