



- R/C controls forward/backward and left/right
- Volume adjustment
- Power display
- Forward and backward
- High and low speed

*Suitable for children of 3-6 years old.

*Max weight: 30 kg.



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION

| | | | | |
|---|--|--|---|---|
|  <p>A x 1</p> <p>Main Body</p> |  <p>B x 1</p> <p>Steering wheel</p> |  <p>C x 4</p> <p>Wheel Cover</p> | | |
|  <p>D x 4</p> <p>Wheel</p> |  <p>E x 1</p> <p>Windshield</p> |  <p>F x 1</p> <p>Rear wing</p> | | |
|  <p>G x 1</p> <p>Seat</p> |  <p>H x 2</p> <p>Rearview mirror</p> |  <p>I x 2</p> <p>Right and left bracket</p> |  <p>J x 6 +1(spare)</p> <p>Washer</p> | |
|  <p>K x 14 +1(spare)</p> <p>Screw</p> |  <p>L x 1</p> <p>Screw</p> |  <p>N x 4</p> <p>Cotter pin</p> |  <p>O x 1</p> <p>Remote Control</p> |  <p>P x 1</p> <p>Charger</p>  <p>Q x 1</p> |



Product Specifications :

| | |
|------------------------|---|
| Battery | 12V/4.5AHx1 |
| Generator | Drive Motor 12V,30W #390 x2 Steering Motor 12V #380 x1 |
| Applicable Age Range | 37-72 months |
| Maximum load | 30KG |
| Speed | 3-5 KM/H |
| Hours of Use | Using 1-2 hours after charging 8-12 hours |
| Charger | Input: AC120V-240V ,50-60Hz,0.2A; Output: DC12V,500mA,6W |
| Remote Control Battery | AAA1.5Vx2(not provided) |

Function



- Button function**
- ① Power display
 - ② Charging hole
 - ③ Power button
 - ④ Siren button
 - ⑤ High and low speed
 - ⑥ Forward and backward


Remote Control Function and explanation

- Never switch forward and backward operations in the moving, or the gear box and motor will be damaged.
- Use the remote control with battery.
- Only the baby's legal guardian can use the remote control.
- The product is operated mainly by remote control.

Code Method:

Hold down Forward & Backward for 3 seconds start match code, The first LED flicker;

Turn on the car's power now, The first LED lit up, Match code Success.



Battery Operating Specifications:

Never mix new and old batteries, or different kinds of batteries.

Never mistake positive and negative electrode of battery, or short circuit will happen.

Non-rechargeable batteries are not to be recharged.

Install batteries in a right polarity.

Only adults can recharge or change batteries.

Never make power port' s short circuit happen.


Recharge the battery only when it is taken out of the toy car.

Take exhausted battery out of the toy car and keep it out of Children's reach.

Remove battery screws with a screwdriver, open battery cap as the arrow signals, and in the 2.4G remote control model install two AAA 1.5V batteries in a right polarity.

1.Right and left bracket assembly

Place the right and left brackets at the corresponding holes on the body and use 10 pcs screw to tighten.



2. Front and rear wheels assembly

Assembling washer, front wheel, washer step by step, then using cotter pin to tighten, finally inserting wheel cover. Assembling rear wheel, washer step by step, then using cotter pin to tighten, finally inserting wheel cover. Same way to the other side.



3. Steering wheel assembly

Connecting two lines like the picture, then inserting the steering wheel to the direction lever, finally use screw and nut to tighten.



4. Windshield assembly

Open the hood, connecting the lines which are in the windshield and under the hood, inserting the windshield into the right place on the platform, finally use 2pcs screw to tighten.




5. Rear wing assembly

Connecting the lines which are in the rear wing and car body, then inserting rear wing into the right hole on the car.



6. Battery line connecting

Connect the battery line correctly, red to red, black to black.



7. Seat assembly

Inserting the seat into the right place in the car, then use 2pcs screw to tighten.



8. Rearview mirror assembly

Inserting right and left rearview mirror into the right place.





WARNING

The toy is to be assembled by an adult. In unassembled state contain potentially hazardous sharp points, sharp edges and small part, so please keep out of baby's reach.

Not to be used in traffic.

Only adults can install parts and adjust the car, and keep moving parts out of children's reach.

Children under 36 months cannot use the toy car as it has many small parts.

Children must take the seat belt when using the car, and keep the car out of the fire.

Children can use the product only in the company of adults, and the adult cannot leave during the process.

Never let Children stand or play onto the pedal or in the car.

Only adults can complete storage battery charging, and must charge the product before its first use.

Keep such package materials as plastic bags out of children, or they will suffocate or kill children.

Never use parts provided by non-manufacturers. Never let children play with the charger.

The number of connected power by the product can never be over the recommended number.

Notice of use:

Never use the product in such dangerous zones as street, road, slope or drain.

Never change the circuit and additional electric devices.

Never use remote control in rainy days or in the water, never pour water or other liquid into the car, keep the product out of the fire, otherwise the car will be damaged.

Only one child can use the product, and its weight cannot exceed 25KGS.

Turn off the power when not in use and remove battery connector when not using it for a long time.

As the product has battery charger, check whether wire plug shell and other parts are damaged or not, and fix those damaged parts.

The product must be assembled by the adult! Before assembling, screws and pins are dangerous sharp points.

Charging notice:

Charge storage battery less than 10 hours, or the storage battery will be damaged forever.

In charging, put DC Plug into the power socket, put charger into power plug; never use the product during charging it.

The product can be used for one hour, and the charging time is 8-10 hours, exceeding no more than 18 hours.

It is common for charger and storage battery to have not become heated (temperature under 60 degrees) in charging.

Never use the connector with the water, or short circuit will happen.

Use the product's own charger, or cause charger and storage battery to be damaged or short circuit.


Charge the product when not using it for a long time.

Charging steps are as follows:

Step 1: The charging hole is under the steering wheel.

Step 2: Put the charger plug into the plug hole.

Step 3: Connect the charger to the power socket.



Warning: Car must be charged by adults only. Car is useless during charging.

Trouble Clearing

| Type | Analysis | Solutions |
|--|--|---|
| The car can not get started. | Low battery voltage; Protection of electric devices; Failure to press the switch button correctly; Falling of power connector; Battery breakdown; Damage of electric devices; Generator breakdown. | Charge battery fully; Use the car a few minutes later; Use the car according to instructions; Install the connector again; Change battery; Change electric devices; Change generator. |
| The battery can not be charged. | Falling of battery connector; No charging for the charger; Charger breakdown. | Install the connector again; Plug the charger again; Change the charger. |
| The car has a short range. | Not full charging of battery; Much-used battery. | Charge fully the battery again; Change the battery. |
| There appear slight noise and heat of the car in charging. | Chemical reactions. | Normal reactions. |
| The car has a slow speed. | Much-used battery; No electricity for battery; Overload; Uneven driving surface. | Change the battery; Charge fully the battery again; Reduce the load below 25 kilograms; Drive on uneven surface. |

Maintenance and Service

Before use children's parents should check whether charge' s wiring, plug, shell and other parts are damaged, and fix those damaged parts.

After using the product for a time, parents should lubricate iron castings with lube, or those castings will get rusted; they should keep the product out of fire and lay it flat in dark places; they should put the product inside the house or cover it with one water-proof cloth in wet whether.

Parents should keep the product out of such hot objects as stove and heater, or its plastic parts may be thawed; they should keep the product out of combustible objects in charging, or the fire may happen.

Parents should clean car surface with one dry cloth, or clean plastic parts with non-waxy furniture polish; they shouldn't clean plastic parts with chemical solutions or clean the car with water; children cannot drive the car in wet or rainy weather, or the car' s generator, circuit system and battery will be damaged.

when not using or laying the product, parents should cut off car power, keeping all the switches into "STOP" or "OFF" model.

Parents mustn't use the fuse which doesn't conform with the agreed specifications.

Parents should' t change product structure and circuit system, and should have the product checked and fixed by professionals or under the guidance of professionals.

UK

If you have any questions, please contact our customer care center.

Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:

MH STAR UK LTD

Unit 27, Perivale Park,

Horsenden lane South

Perivale, UB6 7RH

MADE IN CHINA

