



IN240701130V01_UK



CE



Foot to floor Vehicle

WARNING!

Suitable for children of 18+ months; Max weight: 25 kg.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

User manual

STEERING WHEEL BATTERY INSTALLATION AND REPLACEMENT DIAGRAM



- 1. The battery box is located on the underside of the body.
- 2. Use a screwdriver to loosen the screws and remove the battery compartment cover.
- 3. Remove the battery cover.
- 4. Install 3 pieces of size 5 AA batteries (1.5V), and place them according to the symbols displayed (+,-).
- 5. Close the cover and tighten the screws.
- 6. To remove the batteries, reverse steps 2 and 3.

WARNING

- Must be assembled by an adult, and that in their unassembled state contain potentially hazardous sharp edges or sharp points, or small parts.
- This toy produces flashes that may trigger epilepsy in sensitised individuals

Precaution on installation of batteries

- 1. Children must under adult Supervision when install batteries.
- 2. Keep assembly tools out of sight and reach of children.
- 3. Leaking AA batteries are longer functional and have to throw to the disposable bins properly.
- 4. Do not mix different battery bands within the device, different types of batteries or new and used batteries are not to be mixed.
- 5. Requires 1.5V AA batteries.

- 1.5V + 🗆 × 3
- 6. Non rechargeable batteries can not to be charged.
- 7. Rechargeable batteries are only to be charged under adult supervision.
- 8. Rechargeable batteries must be removed from the product before being charged.


- 9. Install batteries with polarity are shown inside the battery compartment. Batteries are to be inserted with the correct polarity (+ and).
- 10. Remove batteries in charger if necessary.
- 11. Power supply should remain loading to the battery compartment.
- 12. Do not mix old and new batteries.
- 13. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- 14. The supply terminals are not to be short-circuited.
- 15. Exhausted batteries are to be removed from the toy.

Warning

- 1. This product is suitable for children for 18 months;
- This product may have potential sharp edges, tips or small parts before assembly and must be assembled by adults;
- Children should ride this on flat and smooth surface, and should keep away from traffic road; Strictly prohibited in nearby motor vehicles, streets, steps, slopes, hills, roads, alleys, swimming pools or other places with water;
- 4. Keep four wheels on the ground while playing, and do not play on a slope more than 10°.
- This product shall be used under the custody of adults and shall wear shoes;
- This product is only limited to one-person ride, with a maxi mum carrying capacity of 25 kg;
- 7. Adult assembly and installation of all parts are required.
- 8. Do not let Children playing alone with this product prevent from danger of Falling.
- 9. The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.


Maintenance & Care

- 1. Clean the surface frequently using soft cloth.
- 2. Avoid direct sun exposure.
- 3. Periodic inspection and maintenance are required on all fasteners.
- 4. Check Battery status frequently. Store the battery properly for future use.
- 5. Handle with Caution.



INSTRUCTION FOR STICKER





UK

If you have any questions, please contact our customer care center. Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS: MH STAR UK LTD Unit 27, Perivale Park, Horsenden lane South Perivale, UB6 7RH MADE IN CHINA

