



INafb014_UK

A20-171



READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL

EN

A. Bag x1



B. Internal tent x1



C. External tent x1



D. Pole x2




F. Nails x12




G. Wind rope x 4



Open steps:



1. Find the external tent, find the corresponding position of the pole and put it on.



2. Put the pole into the cover pole, fasten the hook button, and put the pole into each corner of the tent.




3. Find the inner tent and hang it inside the outer tent, fix the ground nail and windproof rope.


Storage steps:



1. Remove the inner tent.



2. Pull out the ground nails, the wind rope, remove the hooks.



3. Remove the poles, fold the tent, organize the accessories, and put them in the packaging bag.

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it