



INbtc034_GL

84B-832_84B-832V01




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL

PARTS

A x 1



B x 4




C x 1




HARDWARE

D x 8
+1(spare)



E x 4



F x 1



G x 1



01

A

