

















READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

ASSEMBLY INSTRUCTION


PART LIST

<p>A</p>  <p>desktop 1 pc</p>	<p>B</p>  <p>desk leg 2 pcs</p>	<p>C</p> 	<p>D</p>  <p>down crosspiece 1 pc</p>	<p>E</p>  <p>top crosspiece 1 pc</p>	<p>F</p>  <p>water bottle frame 1 pc</p>	<p>G</p>  <p>earphone frame 1 pc</p>	<p>H</p>  <p>foot nail 4 pcs</p>
<p>I</p>  <p>M6X16mm bolt 12 pcs</p>	<p>J</p>  <p>M6X14mm bolt 2 pcs</p>	<p>K</p>  <p>M4X20mm bolt 10 pcs</p>	<p>L</p>  <p>bolt 4 pcs</p>	<p>M</p>  <p>bolt 2 pcs</p>	<p>N</p>  <p>bolt 2 pcs</p>	<p>O</p>  <p>bolt 2 pcs</p>	<p>P</p>  <p>Allen Key 1 pc</p>

ASSEMBLY


Hx4

01




Ix4

02




Ix4

03




Ix4
Lx4
Jx2

04




Kx10

05



06



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it