

INfga039_UK

370-163



Max weight: 25 kgs.



CE

"Mercedes-Benz" and the design of enclosed product are subject to intellectual property protection owned by Daimler AG. They are used by Ningbo Prince Toys Co., Ltd. under license.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION



WARNING:

- 1.CHOKING HAZARD—Small parts.
- Only allowed for adults to install, keep children away.
- 2. To be used under the direct supervision of an adult.
- 3. Just only allow one child to use.
- 4. Please use on a flat and clean surface. Never use near steps, sloped driveways, hills roadways, alleys, swimming pool areas, road, on grass or wet surfaces or other bodies of water.
- 5.Before driving toy car each time, adult should inspect screws of every parts, please tighten the screw cap if any looseness. secure all fasteners before every ride.
- 6. Always wear shoes and suitable protective equipment. always wear a local standard approved helmet while riding, with the chinstrap securely fastened.
- 7.Do not ride the product at dusk, at night or at times of limited visibility.
- 8. Always comply with local laws and regulations.

MAINTENANCE & CARE

- A. Keep all instructions and parts relating to this product for future reference.
- B. Regularly check for damage and that all screws are securely tightened.
- C. Check that the seat is securely fastened.
- D. Lubricate the chain as often as required.
- E. Regularly check tyre pressures.

Battery Handling:

- 1-Battery must be handled by adults only.
- 2-Always remove exhausted batteries.
- 3-Use AA size batteries only.
- 4-Alkaline batteries are recommended.
- 5-Always remove batteries when the unit is not going to be used for an extended period of time.
- 6-When replacing new batteries, ensure all batteries are replaced.
- 7-Do not mix old and new batteries.
- 8-Do not mix Alkaline, Standard (Carbon-Zinc), or Rechargeable (Nickel-Cadmium) batteries.
- 9-Do not dispose of batteries in fire, batteries may explode or leak.
- 10-Non-rechargeable batteries are not to be recharged
- 11-Rechargeable batteries are to be removed from the toy before being charged
- 12-Rechargeable batteries are only to be charged under adult supervision
- 13-Batteries are to be inserted with the correct polarity
- 14-The supply terminals are not to be short-circuited

COMPONENTS LIST

1. Car body 1 pc



2. Steering wheel 1 pc



3. Backrest 1 pc



4. Screw 3pcs (1 replacement piece)




5. Spare tire 1 pc



6. J-Shaped Stick 1 pc



INSTRUCTIONS




How to assemble the J-shaped stick

- Install the J-shaped stick at the assigned location as picture




How to assemble the backrest

- -Place the backrest over the holes in the rear of the body.
- -While holding the front of the vehicle down one hand push firmly down on the backrest to seat the backrest into the holes. Be certain the backrest is completely seated.



How to assemble the steering wheel.

- -Loosen the bolt and nut in the steering wheel.
- -Place the steering wheel over the J-shaped stick.
- -Insert the bolt and tighten the nut with a screwdriver.



How to assemble the spare tire

- -Place the spare tire in the rear of car body.
 -Tight two screws with a screwdriver.



How to exchange the battery.

- -Loosen the screws with a screwdriver.
- -Put 2AA batteries in the battery house.
- -Then tight the screw with a screwdriver.





001-877-644-9366

customerservice@aosom.com

0033-1-84166106 contact@aosom.fr



001-855-537-6088 customerservice@aosom.ca



0044-800-240-4004 enquiries@mhstar.co.uk



0049-(0)40-88307530 service@aosom.de



0034-931294512 atencioncliente@aosom.es



0039-0249471447 clienti@aosom.it